

# BALUSTRADING FITTINGS GUIDE

1



2 Saddle Anchors 5mm, 1 Jaw/Jaw Bottlescrew Tensioner M5, 2 Swaged Thimbled Eyes 3mm. Use with screws or pop rivets.

2



2 Saddle Anchors 5mm, 1 Eye/Eye Turnbuckle Tensioner M5, 2 Swaged Thimbled Eyes 3mm. Use with screws or pop rivets.

3



2 Screw Eye Anchors (Suitable for timber posts), 1 Jaw/Jaw Bottlescrew Tensioner M5, 2 Swaged Thimbled Eyes 3mm.

4



1 Button Head Socket Screw, 1 Internal Threaded Terminal M5, 1 Dome terminal 1/8". (Recommended for steel posts only)

5



1 Hex Tensioner M6, 1 Swage Stud 1/8" x M6, 1 Dome Terminal 1/8". (Recommended for steel posts only)

6



1 Hex Nut, 2 Swage Studs 1/8" x M5, 1 Dome Nut. (Choice of Dome or Hex nut )

7



1 Swage Stud Lag Screw 1/8" LHT, 1 Swage Stud Lag Screw 1/8" RHT. (Suitable for timber posts only)

8



2 Screw Eye Anchors (Suitable for timber posts), 1 Mini Jaw/Tube Bottlescrew Tensioner, 1 Mini Fork Terminal.

9



2 Saddle Anchors 5mm, 1 Jaw/Tube Bottlescrew Tensioner M5, 1 Fork Terminal 5mm pin. Use with screws or pop rivets.

10



2 Nutserts 6mm, 2 Micro Screw Eye Bolts 6mm, 1 Jaw/Tube Bottlescrew Tensioner M5, 1 Fork Terminal 5mm pin. (Recommended for steel posts only)

11



2 Screw Eye Anchors (Suitable for timber posts), 1 Jaw/Tube Bottlescrew Tensioner M5, 1 Fork Terminal 5mm pin.

Suitable for 7 X 7 wire

This group recommended for use over short spans

Suitable for 1 x 19 wire